

CONTROL GREEN

Item 19205: 5 Gallon Pail & 55 Gallon Drum

ILC DOVER
creating what's next

Grayling
environmental safety products



Control Green is the first environmentally friendly mastic remover that has been developed exclusively to comply with the State of California's stringent air pollution regulations, Code 94507-94571, Title 17.

This low odor mastic remover is a safe, active solvent for dissolving asphaltic floor tile mastics and adhesives. This formula also wets out asbestos fibers, preventing them from becoming airborne. Control Green contains special emulsifiers that aid in preparing the surface for new adhesives.

Application:

Apply Control Green over exposed adhesives by manually pouring or using a low pressure garden sprayer. Spread the product over a 5'x 5' square area entirely saturating the space. Agitate the product over the exposed adhesive with a stiff bristle brush, working the product into the surface. After the adhesive is completely dissolved push or squeeze the liquefied mastic to the next 5'x 5' work area and repeat the process. Stubborn areas may require more aggressive agitation with a long handle scraper. Pick up the liquefied mastic with absorbents. Rinse the surface with water and detergent to remove any residual liquefied mastic. Dispose of waste material according to all Federal, State, County and local regulations.

Stubborn tiles can be lifted by dyking off the area and submersing the tile in Control Green. Cover the tile with a sheet of polyethylene and let soak overnight. The tile should be easily removed the next day.

Product Data:

Type:	Hydrotreated Petroleum Blend
Color:	Clear Green
Odor:	Extremely Mild
Kauri-Butanol Value:	36
Evaporation Rate:	0.025
Vapor Density:	6.1
Boiling Point:	417-468°F
Flash Point:	175°F
Flammable Limits:	LEL: 0.7 – UEL: 10.6
Weight:	6.807 per gallon
Specific Gravity:	0.817
Shelf Life:	1 year
Reactivity:	Stable
NFPA HFR:	1-2-0
Application:	Manual, Airless
Coverage:	up to 200 sq. ft/gallon
Clean-up:	Water & Detergent
Solubility:	Water Emulsifiable

Cautions:

- Do not use in confined space. Ventilate area.
- Intentional misuse by deliberately concentrating and inhaling the product may be harmful or fatal.
- Vapors are heavier than air and will accumulate in low lying areas.
- Store no longer than one year. Store below 120°F.
- Combustible liquid. Keep away from heat, open flame or sparks.
- Flash point 175°F, TCC method.
- Test before use. May be harmful to plastic, rubber and painted surfaces.
- Fire extinguishing media: CO₂, Dry Chemical, Alcohol Foam.
- Use non-sparking tools.
- Avoid skin and eye contact. Avoid breathing mist.
- Approved hand, eye and respiratory protection is recommended.
- Adhere to federal, state and local regulations with using or disposing of this product.
- Refer to important information on the Material Safety Data Sheet.
- HFR Rating 1-2-0

MKT-0162

ILC DOVER
creating what's next

Grayling
environmental safety products