



Grayling™ Anti-Static Liners for Drums and FIBCs — L2 Liners

SAFER FILLING AND DISPENSING FOR PRODUCT WITH STATIC BUILD UP

Certain bulk products pose a danger of combustion or flammability during filling and dispensing which require an L2 liner for safety and to prevent electrical discharge that could lead to a fire or an explosion. Anti-Static liners are specially formulated with film additives that dissipate static charges away from potentially flammable products and eliminate dry chemical static cling.

ANTI-STATIC LINERS FOR DRUMS | L2 LINERS

Grayling™ anti-static drum liners are available for 30 gal and 55 gal drums. Our drum liners extend the life of your drums and reduce or eliminate cleaning costs.

ANTI-STATIC LINERS FOR FIBCS | L2 LINERS

Grayling™ form-fit anti-static liners are custom manufactured to your FIBCs dimensions. This form-fit eliminates wasted space, stress points in the liner and allows the FIBC to fill evenly. Because the FIBC fills more completely, the package is more stable and stacks better. Grayling liners can be made with fill/discharge spouts designed to fit the exact dimensions of your equipment. This virtually eliminates the potential for dusting and leakage as well as speeding the fill and discharge process.

ANTI-STATIC LINERS FOR DRUMS AND FIBCS — L2 LINERS

FIBC BULK BAG LINER CLASSIFICATION

Liner Type	Anti-Static Properties	Surface Resistivity	FIBC Type
L1	Conductive	$\leq 10^7 \Omega$	C
L2	Anti-Static	$10^9 \Omega$ to $10^{12} \Omega$	B, C & D
L3	Resistive with low breakdown voltage (<4kV)	greater than $10^{12} \Omega$	B

FEATURES & BENEFITS

- Liner materials available with migratory or permanent anti-static which can provide 3-5 years of shelf life
- FDA compliant film
- EU 10/2011 Compliant

APPLICATIONS

- Anti-Static liners for FIBCS are used with dry flowable products that pose a danger of combustion or flammability. They are used with Type C bulk bags or FIBCS.
- Anti-static drum liners are commonly used to store paints, sealants, chemicals, powdered products, and adhesives.



One Moonwalker Road
Frederica, DE 19946 USA
+1.302.335.3911
+1.800.631.9567
customer_service@ilcdover.com

www.ilcdover.com