



SENTINEL XT CLEAR™

WELL-SUITED FOR PHARMA

WELL-SUITED FOR SAFETY

ILC Dover designed the spacesuits for the Apollo mission, and we continue to outfit the current generation of astronauts. All of that experience and expertise goes into our Sentinel XT Clear™ powered air-purifying respirator, designed especially for the pharmaceutical industry.

ILC Dover's Sentinel Clear™ Hood, combined with its XT blower, is a best-in-class powered air purifying respirator (PAPR) that delivers an Assigned Protection Factor (APF) of 1,000 for a full 12 hours of operation. It's the clear choice for pharma in-house manufacturing and contract manufacturing organizations that must safeguard employees from airborne particles, cleaning solvents, and bioactive ingredients.



The Sentinel XT Clear system is the only PAPR that offers a clear hood engineered with advanced film technology for excellent visibility, comfort, and mission-critical protection. Think of it as a spacesuit for pharma.

WELL-SUITED FOR PRODUCTIVITY

The Sentinel XT Clear PAPR is a superior solution when compared to other PAPR masks and facepieces. It offers a full 320-degree field of view, allows the wearer to have facial hair and/or a head covering, and reduces feelings of claustrophobia.

SMART SYSTEM DESIGN

Multiple filter and breathing tube options ensure that the assembly is easy to use and supports a range of applications.

STRONG, LIGHTWEIGHT BLOWER

The XT blower, when paired with ILC Dover's lithium polymer battery, weighs just 2.2 pounds, yet delivers 8+ CFM airflow, exceeding NIOSH requirements. A nonincendive configuration is available for use in hazardous locations.

IMPROVED ERGONOMICS

Our back harness and Quick-Loc™ belt options support a range of user needs and preferences while increasing comfort and usability.

WELL-SUITED FOR PHARMA

ILC Dover may not be a household name in the pharmaceutical industry, but discerning manufacturers have trusted our products for years, both for containment and for personal protection. We've earned this trust by designing highly engineered solutions that perform reliably when failure is not an option. Explore below to see how the Sentinel XT Clear™ system is well-suited for pharma.

TECHNICAL SPECIFICATIONS

SENTINEL CLEAR HOOD

Assigned Protection Factor	1,000
Field of View	320 degrees
Configuration/design	Inner and outer bibs for easy donning and protection from breach — unique skirt/exhaust system inflates suit to deliver improved protection and comfort
Material	Non-woven, spunbond, polyethylene coated, polyolefin and polyethylene film
Lens Material	Polyester film (PET)
Sizing	Universal
Standards	NIOSH-approved

SENTINEL XT BLOWER/BATTERY

Motor	Brushless, no-spark design, with a high torque-to-weight ratio for greater operating efficiency
Battery Composition	Lithium polymer
Battery Life	12 hrs
Battery Mount	Direct snap-on to blower
Weight	2.2 lbs
Airflow	8 scfm (230 lpm)
Noise Level	<75 dB
Indicators	External battery life indicator gauge shows charge level
Cartridge Interface	40 mm rolled threads — integration with integral blower gaskets
Standards	XT/NI system is Factory Mutual Global Group approved for service in Class I, II and III, as well as in Division 2, Group C, D, E, F and G hazardous locations

FILTERS

Particulate Protection	P100/HEPA cartridges
Organic Vapor and Acid Gas Protection	OV/AG/HE cartridges
Additional Protections	Multi-hazard cartridges provide protection against ammonia, methylamine, formaldehyde, chlorine, sulfur dioxide, hydrogen chloride, chlorine dioxide and hydrogen fluoride
Attachment	40 mm

ACCESSORIES

Breathing Tubes	25- and 33-inch lengths — available with breathing tube and blower covers
Battery Charger	Charging cradle/charger
Flowmeter	Easy-to-use flowmeter to test airflow
Ergonomic Options	Quick-Loc decon belt is easy to use and clean — adjustable back harness ideal for seated applications



SUIT UP! SCHEDULE A DEMO WITH ONE OF OUR EXPERTS

ILC Dover maintains an uncompromised commitment to environmental health and safety, and we look forward to collaborating with you to keep your workers safe and comfortable. To learn more or to request a demo of the Sentinel XT Clear PAPR system, contact us today — and see firsthand why pharmaceutical manufacturers have trusted ILC Dover for more than 10 years.



One Moonwalker Road
Frederica, DE 19946 USA
+1.302.335.3911
+1.800.631.9567

customer_service@ilcdover.com

www.ilcdover.com

© 2019 ILC Dover. All rights reserved.

