



Grayling™ Bulk Packaging for Dry Food Applications



DRIVE YOUR MANUFACTURING EFFICIENCY WHILE PROTECTING YOUR PRODUCT

Intermediate Bulk Container Liners offer an efficient and reliable means to fill, transport and discharge your dry food products. Bulk liners paired with FIBCs or drums can be used for bulk processing in-house or to more economically ship your dry products to food processors and contract packagers.

- Food grade bulk liners help you deliver your products safely by protecting the product packed from contamination during processing, storage, and transportation
- Liners can be custom designed for specific applications so that they optimize your filling and dispensing operations

APPLICATIONS

- Dry Mixes
- Spices
- Sugar & Confectionery
- Vitamins & Supplements
- Nuts & Grains
- Coffee

Our production facility is FSSC22000, Kosher and IMS certified

Intermediate Bulk Packaging Solutions for Dry Food Products



DESIGNED FOR YOUR DEMANDS



FORM-FIT LINERS

Form-fit liners are custom designed to fit the dimensions of the FIBC providing maximum filling and dispensing efficiency through complete discharging of your product. Unlike a basic "tube liner", Form-Fit Liners offer a flat top and bottom and incorporate a spout diameter and length to best compliment the FIBC'S fill and discharge spouts.

32" square up to 48" square

43"x 37" up to 48"x 43"

*We also produce open top liners for gaylords up to 48"

- Liners are manufactured with film structures for your specific application performance needs; moisture or oxygen barrier, UV inhibition, toughness and durability, anti-static properties (L2)
- We can produce bag-on-roll liners up to 48" on our fully automated equipment that provides customers with ease of use
- Form-fit liners can be made with attachment tabs which allow you to sew, tie or glue in the liner eliminating the chance of liner discharge
- The spouts of form-fit liners can be heat-sealed for added sanitation and product protection



FOIL LINERS

Constructed from aluminum foil, form-fit foil liners offer an impermeable barrier providing the highest level of ideal protection from oxygen, moisture and UV.

38" square up to 47" square
38"x33" up to 47" x 45"

Lay flat pouches in widths
30" up to 47"



DRUM LINERS

Designed for use with steel, plastic or fiber drums, liners ensure that your dry food products stay pure and contamination free. Our drum liners are manufactured using engineered polyethylene film structures to provide durability, consistency and performance.

30/55 gallon lay flat "bag on a roll"
or round bottom with diameters of
14", 20" or 23"



ILC Dover LP
100 Discovery Blvd, Suite 1001
Newark, DE 19713 USA
+1.302.335.3911
+1.800.631.9567
customer_service@ilcdover.com

www.ilcdover.com